AMI-Based Apache Web Server Deployment on AWS EC2

Create a VPC


- 1. Go to VPC Console (search "VPC" in AWS Console).
- 2. Left menu \rightarrow Your VPCs \rightarrow Create VPC.
- 3. Choose VPC only.
- 4. Fill in:

Name tag: MyLab-VPC

IPv4 CIDR block: 10.0.0.0/16 (gives 65k IPs, fine for labs)


Leave other defaults.

5. Click Create VPC.




Create an Internet Gateway (IGW)

- 1. Left menu → Internet gateways → Create internet gateway.
- 2. Name: MyLab-IGW → Create.



3. Select it \rightarrow **Actions** \rightarrow **Attach to VPC** \rightarrow choose MyLab-VPC.



Create a Public Subnet

1. Left menu \rightarrow Subnets \rightarrow Create subnet.

2. Choose:


VPC: MyLab-VPC

Subnet name: Public-Subnet-1


Availability Zone: e.g. ap-south-1a

IPv4 CIDR block: 10.0.1.0/24 (gives 256 IPs)

3. Click Create subnet.



- 4. Go to Subnets → select Public-Subnet-1.
- 5. Actions → Modify subnet settings.
- 6. Check **Enable auto-assign public IPv4 address** → Save.




Create and Configure a Route Table

1. Left menu \rightarrow Route tables \rightarrow Create route table.

Name: Public-RT

VPC: MyLab-VPC → Create.



 Select Public-RT → Subnet associations → Edit subnet associations → check Public-Subnet-1 → Save.




3. Go to **Routes tab** \rightarrow **Edit routes** \rightarrow Add route:

Destination: 0.0.0.0/0

Target: your MyLab-IGW

Save changes.




Now your subnet is "public" (it routes traffic to the Internet).

Security Group


- 1. Choose Create a new security group.
- 2. Creating new, add rules:

SSH \rightarrow Type: **SSH**, Protocol: TCP, Port: 22, Source: **My IP** (choose "My IP" to restrict). **HTTP** \rightarrow Type: **HTTP**, Protocol: TCP, Port: 80, Source: **0.0.0.0/0** (allows public access to web server).



Launch Ubuntu EC2 (Console)

- 1. $EC2 \rightarrow Instances \rightarrow Launch instances$.
- 2. Give name eg. EC2-Ubuntu-1
- 3. *Image*: choose **Ubuntu Server**.
- 4. Instance type: e.g. t3.micro (or whatever).
- 5. Key pair: select existing.
- 6. Network / subnet: pick a public subnet (ensure Auto-assign Public IP = Enable).
- 7. Security group: choose that we have created above.
- 8. Launch.



SSH in, install Apache, verify (commands to run on your machine after instance is running)

Replace <KEY.pem> and <PUBLIC_IP> with your values.

chmod 400 <KEY.pem>

ssh -i "<KEY.pem>" ubuntu@<PUBLIC IP>

```
System information as of Thu Sep 4 89:55:80 UTC 2025

System load: 8.83
Usage of: 25.68 of 6.71GB
Processes: 115
Memory usage: 238
Users logged in: 8
Symap usage: 84
Users logged in: 8
Users logged in: 9
```

Once on the instance:

update packages

sudo apt upgrade -y

```
System information as of Thu Sep 409:55:00 UTC 2025

System load: 0.03
Usage of 2: 25.6% of 6.71GB Processes: 115
Memory usage: 23%
Memory usage: 24%
Memory usage: 24%
Memory usage: 25%
Memory
```

install Apache

sudo apt install -y apache2

```
Enabling module author.file.
Enabling module author.gitle.
Enabling module mognitation.
Enabling module mognitation.
Enabling module mognitation.
Enabling module mognitation.
Enabling module experimence.
Enabling module seteror.
Enabling module requirement.
Enabling mo
```

enable and start Apache

sudo systemctl enable --now apache2

```
Enabling module alias.
Enabling module alias.
Enabling module autorindex.
Enabling module autorindex.
Enabling module autorindex.
Enabling module setenvif.
Enabling module se
```

From your laptop/browser: open http://<PUBLIC_IP>/ — you should see the default Apache2 Ubuntu page.



Create an AMI of that instance


Console (simplest)

- 1. $EC2 \rightarrow Instances \rightarrow select$ the Ubuntu instance that u have create above.
- 2. Actions → Image and templates → Create image.

Name: e.g. ubuntu-apache-AMI

Leave volumes as-is (root volume included).


3. Click Create image.



4. $EC2 \rightarrow Images \rightarrow AMIs \rightarrow wait until the AMI state becomes available.$

Terminate the original instance (Console)


- EC2 → Instances → select the instance → Instance state → Terminate instance → confirm.
- 2. Wait for state to change to terminated.




Terminating is permanent for that instance ID; AMI remains available in **Images** → **AMIs**.

Launch new instance from your AMI

- 1. $EC2 \rightarrow Launch instances$.
- 2. Under My AMIs (left) \rightarrow select the AMI you created.
- 3. Give name eg. EC2-Ubuntu-AMI
- 4. Set Instance type (e.g. t3.micro).
- 5. Configure network/subnet: choose as before (public subnet + auto-assign public IP if you want browser access).
- 6. Select or create Security Group (must allow SSH and HTTP).
- 7. Choose key pair (same or different).
- 8. Launch. EC2 will create instances from the same AMI (It will have Apache already installed and your default page present).





Then test in browser: http://<new-instance-public-ip>/ — you should see the same Apache default page.

